How to install the tail section and dorsal fin